



V = VAPORE
STEAM
VAPEUR

A = ARIA C.
AIR.C
AIR.C

| | | | | |
|---|---------------|-----------|----------|-------------|
| PRESOSTATO MATER CON BOX MATER - PRESSURE SWITCH IN BOX PRESSOSTAT - MATER AVEC BOX | 1-4" M | 0 - 6 Bar | V | Cod. 120.01 |
| | 1-4" M | 0 - 9 Bar | V | Cod. 120.09 |



PRESOSTATO MATER SENZA BOX
MATER - PRESSURE SWITCH WITHOUT BOX
PRESSOSTAT - MATER SANS BOX

| | | | |
|---------------|-----------|----------|-------------|
| 1-4" M | 0 - 6 Bar | V | Cod. 120.10 |
|---------------|-----------|----------|-------------|



PRESOSTATO MANUALE DI SICUREZZA SOVRAPRESSIONE
MANUAL PRESSURE- SWITCH FOR SAFETY OVERLOAD
PRESSOSTAT MANUEL POUR SECURITE SUR-PRESSION

| | | | |
|---------------|-------------|----------|-------------|
| 1-4" M | 3 - 7,5 Bar | V | Cod. 120.07 |
|---------------|-------------|----------|-------------|



PRESOSTATO CEME
CEME - PRESSURE SWITCH
PRESSOSTAT - CEME

| | | | |
|---------------|-----------|----------|-------------|
| 1-4" M | 0 - 6 Bar | V | Cod. 120.03 |
|---------------|-----------|----------|-------------|



PRESOSTATO
PRESSURE SWITCH
PRESSOSTAT

| | | | |
|---------------|------------|----------|-------------|
| 1-4" F | 0 - 11 Bar | A | Cod. 120.02 |
|---------------|------------|----------|-------------|